



Maintenance Highlights

Care and Maintenance:

Basic precautions and care will insure that your XGrass Play Surface will maintain its appearance and optimum performance for many years. These tips are not expensive and do not take a lot of time, but can do a lot to protect your investment for future use.

Precautions:

- Keep any kind of flame (cigarettes, charcoal grills, fireworks, etc.) away from the surface.
- Keep gasoline, oil or any other petroleum-based chemicals away from the surface.
- Keep surface free of leaves, grass clippings, or other debris. A good leaf blower works well to help keep the surface clean.
- Be careful when using any type of edging tools near the edge of the surface.
- The turf will resist the harmful effects of rain, snow, and ice. Some color loss is inherent in the product and will not affect the quality of the surface.

Recommended Maintenance Schedule:

Monthly:

Brush Surface – this process involves using a power broom or a push broom. The operator should sweep against the fibers to stand up the blades of turf.

As needed:

Top Dress – this process involves using a drop spreader with the acrylic coated sand and apply where needed to fill in low spots.